

List of Paris MoU deficiency codesⁱ

Code	Defective item
01 - Certifica	ates & Documentation
011 - Certifica	ates & Documentation - Ship Certificate
01101	Cargo ship safety equipment (including exemption)
01102	Cargo ship safety construction (including exempt.)
01103	Passenger ship safety (including exemption)
01104	Cargo ship safety radio (including exemption)
01105	Cargo ship safety (including exemption)
01106	Document of compliance (DoC/ ISM)
01107	Safety management certificate (SMC/ ISM)
01108	Load lines (including Exemption)
01109	Decision-support system for masters on pass. ships
01110	Authorization for grain carriage
01111	Liquefied gases in bulk (CoF/GC Code)
01112	Liquefied gases in bulk (CoF/IGC Code)
01113	Minimum safe manning document
01114	Dangerous chemicals in bulk (CoF/BC Code)
01115	Dangerous chemicals in bulk (CoF/IBC Code)
01116	Operational limitations for passenger ships
01117	Prevention of pollution by oil (IOPP)
01118	Pollution prevention by noxious liquid sub in bulk
01119	International sewage pollution prevention Cert.
01120	Statement of Compliance CAS
01121	Interim Statement of Compliance CAS
01122	International ship security certificate
01123	Continuous synopsis record
01124	International Air Pollution Prevention Cert
01125	Engine International Air Pollution Prevention Cert
01126	Document of compliance dangerous goods
01127	Special purpose ship safety
01128	High speed craft safety and permit to operate
01129	Mobile offshore drilling unit safety
01130	INF certificate of fitness
01131	International AFS certificate
01132	Tonnage certificate
01133	Civil liability for oil pollution damage cert.
01134	Other (certificates)
01135	Document for carriage of dangerous goods
01136	Ballast Water Management Certificate
01137	Civil liability for Bunker oil pollution damage cert
040 0 == 1'0'	otes 9 Decompositation Communication
	ates & Documentation - Crew Certificate
01201	Certificates for master and officers
01202	Certificate for rating for watchkeeping
01203	Certificates for radio personnel
01204	Certificate for personnel on tankers



Code Defective item 01205 Certificate for personnel on fast rescue boats 01206 Certificate for advanced fire-fighting 01207 Doc evidence for personnel on passenger ships	
01206 Certificate for advanced fire-fighting	
U1207 Doc evidence for personnel on passenger snips	
04000 D :1 (1	
01208 Doc evidence for personnel on ro-ro passenger ship	
01209 Manning specified by the minimum safe manning doc	
01210 Certificate for medical first aid	
01211 Cert for personnel on survival craft & rescue boat	
01212 Certificate for medical care	
01213 Evidence of basic training	
01214 Endorsement by flagstate	
01215 Application for Endorsement by flagstate	
01217 Ship Security Officer certificate	
013 - Certificates and Documentation - Document	
01301 Cargo gear record book	
01302 SAR co-operation plan for pass.ships trade on fixed route	
01303 Unattended machinery spaces (UMS) evidence	
01304 Declaration of AFS compliance	
01305 Log-books/compulsory entries	
01306 Schedules for watchkeeping personnel	
01307 Tables of working hours	
01308 Records of rest	
01309 Fire control plan – all	
01310 Signs, indications	
01311 Survey report file	
01312 Thickness measurement report	
01313 Booklet for bulk cargo loading/unloading/stowage	
01314 Shipboard oil pollution emergency plan (SOPEP)	
01315 Oil record book	
01316 Cargo information	
01317 Cargo record book	
01318 P & A manual	
01319 Shipboard mar. poll. Emergency plan (MPEP) for NLS	
01320 Garbage record book	
01322 Conformance Test Report	
01323 Fire safety operational booklet	
01324 Material safety data sheets	
01325 ACM statement of compliance (including exemption)	
02 - Structural condition	
02101 Closing devices/watertight doors	
02102 Damage control plan	
02103 Stability/strenght/loading information and instruments	
02104 Information on the A/A-max ratio (Roro/pass.only)	
02105 Steering gear	
02106 Hull damage impairing seaworthiness	



Code	Defective item
02107	Ballast, fuel and other tanks
02108	Electric equipment in general
02109	Permanent means of access
02110	Beams, frames, floors-oper.damage
02111	Beams, frames, floors-corrosion
02112	Hull - corrosion
02113	Hull - cracking
02114	Bulkhead -corrosion
02115	Bulkheads - operational damage
02116	Bulkheads – cracking
02117	Decks – corrosion
02118	Decks – cracking
02119	Enhanced survey programme (ESP)
02120	Marking of IMO number
02121	Cargo area segregation
02122	Openings to cargo area, doors,, scuttles
02123	Wheelhouse door, -window
02124	Cargo pump room
02125	Spaces in cargo areas
02126	Cargo tank vent system
02127	Safe access to tanker bows
02128	Bulk carriers additional safety measures
02129	Bulkhead strength
02130	Triangle mark
02131	Other (Bulk carriers)
02132	Water level detectors on single hold cargo ships
02133	Asbestos containing materials
03 - Water/M	/eathertight condition
03 - Water/W	Overloading
03102	Freeboard marks
03103	Railing, gangway, walkway and means for safe passage
03104	Cargo and other hatchways
03105	Covers (hatchway-, portable-, tarpaulins, etc.)
03106	Windows, side scuttles and deadlights
03107	Doors
03108	Ventilators, air pipes, casings
03109	Machinery space openings
03110	Manholes / flush scuttles
03111	Cargo ports and other similar openings
03112	Scuppers, inlets and discharges
03113	Bulwarks and freeing ports
03114	Stowage incl. uprights, lashing, etc (timber)
03115	Other (load lines)



04102 Emergency Systems 04103 Emergency lighting batteries and switches 04104 Low level lighting in corridors 04105 Cocation of emergency installations 04106 Emergency steering position communications/ compass reading 04106 Emergency steering position communications/ compass reading 04107 Emergency towing arrangements and procedures 04108 Muster list 04109 Fire drills 04110 Abandon ship drills 04111 Damage control plan 04112 Shipboard Marine Pollution emergency operations 04113 Water level indicator 04114 Emergency source of power - Emergency generator 05 - Radio communication 05101 Distress messages: obligations and procedures 05102 Functional requirements 05103 Main installation 05104 MF radio installation 05105 MF/HF radio installation 05106 INMARSAT ship earth station 05107 Maintenance / duplication of equipment 05108 Performance standards for radio equipment 05109 VHF radio installation 05101 Sacillites for reception of marine safety information 05101 Sacillites for reception of marine safety information 05111 Sacillites for reception of marine safety information 05111 Sacillite EPIRB 406MHz / 1.6 GHz 05112 Radio log (diary) 05113 Radio log (diary) 05114 Operation/maintenance 05117 Other (radio communication) 05118 Operation of GMDSS equipment 06101 Cargo operations including equipment 06101 Cargo securing manual 06102 Grain 06103 Other cargo - timber -deck/construction 06104 Lashing material 06105 Cargo density declaration		Code	Defective item
04101 Public address system 04102 Emergency lighting, batteries and switches 04104 Low level lighting in corridors 04105 Location of emergency installations 04106 Emergency steering position communications/ compass reading 04107 Emergency towing arrangements and procedures 04108 Muster list 04109 Fire drills 04110 Abandon ship drills 04111 Damage control plan 04112 Shipboard Marine Pollution emergency operations 04113 Water level indicator 04114 Emergency source of power - Emergency generator 05- Radio communication 05101 05101 Distress messages: obligations and procedures 05102 Functional requirements 05103 Main installation 05104 MF radio installation 05105 MF/HF radio installation 05106 MF/HF radio installation 05107 Maintenance / duplication of equipment 05108 Performance standards for radio equipment 05110 Facilities EPIRB	04 -	Emerge	ncy Systems
04103 Emergency lighting,batteries and switches 04104 Low level lighting in corridors 04105 Location of emergency installations 04106 Emergency steering position communications/ compass reading 04107 Emergency towing arrangements and procedures 04108 Muster list 04110 Abandon ship drills 04111 Damage control plan 04112 Shipboard Marine Pollution emergency operations 04113 Water level indicator 04114 Emergency source of power - Emergency generator 05 - Radio communication 05101 Distress messages: obligations and procedures 05102 Functional requirements 05103 Main installation 05104 MF radio installation 05106 INMARSAT ship earth station 05107 Maintenance / duplication of equipment 05108 Performance standards for radio equipment 05109 Performance standards for radio equipment 051010 Facilities for reception of marine safety information 05111 Satellite EPIRB 406MHz / 1.6 GHz 05112 VHF EPIRB 05113 SART/AIS-SART 05114 Reserve source of energy 05115 Radio log (diary) 05116 Operation/maintenance 05117 Other (radio communication) 05118 Operation of GMDSS equipment 06101 Cargo operations including equipment 06102 Grain 06103 Other cargo - timber -deck/construction 06104 Lashing material 06105 Cargo transfer - Tankers 06107 Cargo operation			
04104 Low level lighting in corridors 04105 Location of emergency installations 04106 Emergency steering position communications/ compass reading 04107 Emergency towing arrangements and procedures 04108 Muster list 04109 Fire drills 04110 Abandon ship drills 04111 Damage control plan 04112 Shipboard Marine Pollution emergency operations 04113 Water level indicator 04114 Emergency source of power - Emergency generator 05 - Radio communication 05101 Distress messages: obligations and procedures 05102 Functional requirements 05103 Main installation 05104 MF radio installation 05105 MF/HF radio installation 05106 INMARSAT ship earth station 05107 Maintenance / duplication of equipment 05108 Performance standards for radio equipment 05109 VHF radio installation 05101 Sacilities for reception of marine safety information 05111 Satellite EPIRB 406MHz / 1.6 GHz 05112 VHF EPIRB 05113 SART/KJS-SART 05114 Reserve source of energy 05115 Radio log (diary) 05116 Operation/maintenance 05117 Other (radio communication) 05118 Operation of GMDSS equipment 06101 Cargo securing manual 06102 Grain 06103 Other cargo - timber -deck/construction 06104 Lashing material 06105 Cargo transfer - Tankers 06107 Cargo operation		04102	Emergency fire pump and its pipes
04105 Location of emergency installations 04106 Emergency steering position communications/ compass reading 04107 Emergency towing arrangements and procedures 04108 Muster list 04109 Fire drills 04110 Abandon ship drills 04111 Damage control plan 04112 Shipboard Marine Pollution emergency operations 04113 Water level indicator 04114 Emergency source of power - Emergency generator 05 - Radio communication 05101 Distress messages: obligations and procedures 05102 Functional requirements 05103 Main installation 05104 MF radio installation 05105 MF/HF radio installation 05106 INMARSAT ship earth station 05107 Maintenance / duplication of equipment 05109 VHF radio installation 05109 Performance standards for radio equipment 05109 VHF radio installation 05110 Facilities for reception of marine safety information 05111 Satellite EPIRB 406MHz / 1.6 GHz 05112 VHF EPIRB 05113 SART/AIS-SART 05114 Reserve source of energy 05115 Radio log (diary) 05116 Operation/maintenance 05117 Other (radio communication) 05118 Operation of GMDSS equipment 06101 Cargo securing manual 06102 Grain 06103 Other cargo - timber -deck/construction 06104 Lashing material 06105 Other (cargo) 06106 Cargo transfer - Tankers 06107 Cargo operation		04103	Emergency lighting, batteries and switches
04106 Emergency steering position communications/ compass reading 04107 Emergency towing arrangements and procedures 04108 Muster list 04109 Fire drills 04110 Abandon ship drills 04111 Damage control plan 04112 Shipboard Marine Pollution emergency operations 04113 Water level indicator 04114 Emergency source of power - Emergency generator 05 - Radio communication 05101 Distress messages: obligations and procedures 05102 Functional requirements 05103 Main installation 05104 MF radio installation 05105 MF/HF radio installation 05106 MF/HF radio installation 05107 Maintenance / duplication of equipment 05108 Performance standards for radio equipment 05109 VHF radio installation 05110 Facilities for reception of marine safety information 05111 Satellite EPIRB 406MHz / 1.6 GHz 05112 VHF EPIRB 05113 SART/AIS-SART 05114 Reserve source of energy 05115 Sadio log (diary) 05116 Operation/maintenance 05117 Other (radio communication) 05118 Operation of GMDSS equipment 0610 Cargo operations including equipment 06101 Cargo securing manual 06102 Grain 06103 Other cargo - timber -deck/construction 06104 Lashing material 06105 Cargo transfer - Tankers 06107 Cargo operation		04104	Low level lighting in corridors
04107 Emergency towing arrangements and procedures 04108 Muster list 04109 Fire drills 04110 Abandon ship drills 04111 Damage control plan 04112 Shipboard Marine Pollution emergency operations 04113 Water level indicator 04114 Emergency source of power - Emergency generator 05 - Radio communication 05101 Distress messages: obligations and procedures 05102 Functional requirements 05103 Main installation 05104 MF radio installation 05105 MF/HF radio installation 05106 INMARSAT ship earth station 05107 Maintenance / duplication of equipment 05108 Performance standards for radio equipment 05109 VHF radio installation 05110 Facilities for reception of marine safety information 05111 Satellite EPIRB 406MHz / 1.6 GHz 05112 VHF EPIRB 05113 SART/AIS-SART 05114 Reserve source of energy 05115 Radio log (diary) 05116 Operation/maintenance 05117 Other (radio communication) 05118 Operation of GMDSS equipment 06101 Cargo securing manual 06102 Grain 06103 Other cargo - timber -deck/construction 06104 Lashing material 06105 Other (cargo) 06106 Cargo transfer - Tankers		04105	Location of emergency installations
04108 Muster list 04109 Fire drills 04110 Abandon ship drills 04111 Damage control plan 04112 Shipboard Marine Pollution emergency operations 04113 Water level indicator 04114 Emergency source of power - Emergency generator 05 - Radio communication 05101 Distress messages: obligations and procedures 05102 Functional requirements 05103 Main installation 05104 MF radio installation 05105 MF/HF radio installation 05106 IMMARSAT ship earth station 05107 Maintenance / duplication of equipment 05108 Performance standards for radio equipment 05109 VHF radio installation 05110 Facilities for reception of marine safety information 05111 Satellite EPIRB 406MHz / 1.6 GHz 05112 VHF EPIRB 05113 SART/AIS-SART 05114 Reserve source of energy 05115 Radio log (diary) 05116 Operation/maintenance 05117 Other (radio communication) 05118 Operation of GMDSS equipment 06101 Cargo securing manual 06102 Grain 06103 Other cargo - timber -deck/construction 06104 Lashing material 06105 Other (cargo) 06106 Cargo transfer - Tankers 06107 Cargo operation		04106	Emergency steering position communications/ compass reading
04109 Fire drills 04110 Abandon ship drills 04111 Damage control plan 04112 Shipboard Marine Pollution emergency operations 04113 Water level indicator 04114 Emergency source of power - Emergency generator 05 - Radio communication 05101 Distress messages: obligations and procedures 05102 Functional requirements 05103 Main installation 05104 MF radio installation 05105 MF/HF radio installation 05106 INMARSAT ship earth station 05107 Maintenance / duplication of equipment 05108 Performance standards for radio equipment 05109 VHF radio installation 05110 Facilities for reception of marine safety information 05111 Satellite EPIRB 406MHz / 1.6 GHz 05112 VHF EPIRB 05113 SART/AIS-SART 05114 Reserve source of energy 05115 Radio log (diary) 05116 Operation/maintenance 05117 Other (radio communication) 0518 Operation of GMDSS equipment 06101 Cargo securing manual 06102 Grain 06103 Other cargo - timber -deck/construction 06104 Lashing material 06105 Cargo transfer - Tankers 06107 Cargo operation		04107	Emergency towing arrangements and procedures
04110 Abandon ship drills 04111 Damage control plan 04112 Shipboard Marine Pollution emergency operations 04113 Water level indicator 04114 Emergency source of power - Emergency generator 05 - Radio communication 05101 Distress messages: obligations and procedures 05102 Functional requirements 05103 Main installation 05104 MF radio installation 05105 MF/HF radio installation 05106 INMARSAT ship earth station 05107 Maintenance / duplication of equipment 05108 Performance standards for radio equipment 05109 VHF radio installation 05110 Facilities for reception of marine safety information 05111 Satellite EPIRB 406MHz / 1.6 GHz 05112 VHF EPIRB 05113 SART/AIS-SART 05114 Reserve source of energy 05115 Radio log (diary) 05116 Operation/maintenance 05117 Other (radio communication) 05118 Operation of GMDSS equipment 06101 Cargo securing manual 06102 Grain 06103 Other cargo - timber -deck/construction 06104 Lashing material 06105 Other (cargo) 06106 Cargo transfer - Tankers 06107 Cargo operation		04108	Muster list
04112 Shipboard Marine Pollution emergency operations 04113 Water level indicator 04114 Emergency source of power - Emergency generator 05 - Radio communication 05101 Distress messages: obligations and procedures 05102 Functional requirements 05103 Main installation 05104 MF radio installation 05105 MF/HF radio installation 05106 INMARSAT ship earth station 05107 Maintenance / duplication of equipment 05108 Performance standards for radio equipment 05109 VHF radio installation 05110 Facilities for reception of marine safety information 05111 Satellite EPIRB 406MHz / 1.6 GHz 05112 VHF EPIRB 05113 SART/AIS-SART 05114 Reserve source of energy 05115 Radio log (diary) 05116 Operation/maintenance 05117 Other (radio communication) 05118 Operation of GMDSS equipment 06101 Cargo securing manual 06102 Grain 06103 Other cargo - timber -deck/construction 06104 Lashing material 06105 Other (cargo) 06106 Cargo operations 06107 Cargo operation		04109	Fire drills
04112 Shipboard Marine Pollution emergency operations 04113 Water level indicator 04114 Emergency source of power - Emergency generator 05 - Radio communication 05101 Distress messages: obligations and procedures 05102 Functional requirements 05103 Main installation 05104 MF radio installation 05105 MF/HF radio installation 05106 INMARSAT ship earth station 05107 Maintenance / duplication of equipment 05108 Performance standards for radio equipment 05109 VHF radio installation 05110 Facilities for reception of marine safety information 05111 Satellite EPIRB 406MHz / 1.6 GHz 05112 VHF EPIRB 05113 SART/AIS-SART 05114 Reserve source of energy 05115 Radio log (diary) 05116 Operation/maintenance 05117 Other (radio communication) 05118 Operation of GMDSS equipment 06101 Cargo securing manual 06102 Grain 06103 Other cargo - timber -deck/construction 06104 Lashing material 06105 Other (cargo) 06106 Cargo operations 06107 Cargo operation		04110	Abandon ship drills
04112 Shipboard Marine Pollution emergency operations 04113 Water level indicator 04114 Emergency source of power - Emergency generator 05 - Radio communication 05101 Distress messages: obligations and procedures 05102 Functional requirements 05103 Main installation 05104 MF radio installation 05105 MF/HF radio installation 05106 INMARSAT ship earth station 05107 Maintenance / duplication of equipment 05108 Performance standards for radio equipment 05109 VHF radio installation 05110 Facilities for reception of marine safety information 05111 Satellite EPIRB 406MHz / 1.6 GHz 05112 VHF EPIRB 05113 SART/AIS-SART 05114 Reserve source of energy 05115 Radio log (diary) 05116 Operation/maintenance 05117 Other (radio communication) 05118 Operation of GMDSS equipment 06101 Cargo securing manual 06102 Grain 06103 Other cargo - timber -deck/construction 06104 Lashing material 06105 Other (cargo) 06106 Cargo operations		04111	·
04113 Water level indicator 04114 Emergency source of power - Emergency generator 05 - Radio communication 05101 Distress messages: obligations and procedures 05102 Functional requirements 05103 Main installation 05104 MF radio installation 05105 MF/HF radio installation 05106 INMARSAT ship earth station 05107 Maintenance / duplication of equipment 05108 Performance standards for radio equipment 05109 VHF radio installation 05110 Facilities for reception of marine safety information 05111 Satellite EPIRB 406MHz / 1.6 GHz 05112 VHF EPIRB 05113 SART/AIS-SART 05114 Reserve source of energy 05115 Radio log (diary) 05116 Operation/maintenance 05117 Other (radio communication) 05118 Operation of GMDSS equipment 06101 Cargo securing manual 06102 Grain 06103 Other cargo - timber -deck/construction 06104 Lashing material 06105 Other (cargo) 06106 Cargo operations		04112	
05 - Radio communication 05101 Distress messages: obligations and procedures 05102 Functional requirements 05103 Main installation 05104 MF radio installation 05105 MF/HF radio installation 05106 IMMARSAT ship earth station 05107 Maintenance / duplication of equipment 05108 Performance standards for radio equipment 05109 VHF radio installation 05110 Facilities for reception of marine safety information 05111 Satellite EPIRB 406MHz / 1.6 GHz 05112 VHF EPIRB 05113 SART/AIS-SART 05114 Reserve source of energy 05115 Radio log (diary) 05116 Operation/maintenance 05117 Other (radio communication) 05118 Operation of GMDSS equipment 06101 Cargo securing manual 06102 Grain 06103 Other cargo - timber -deck/construction 06104 Lashing material 06105 Other (cargo) 06106 Cargo operation		04113	
05 - Radio communication 05101 Distress messages: obligations and procedures 05102 Functional requirements 05103 Main installation 05104 MF radio installation 05105 MF/HF radio installation 05106 IMMARSAT ship earth station 05107 Maintenance / duplication of equipment 05108 Performance standards for radio equipment 05109 VHF radio installation 05110 Facilities for reception of marine safety information 05111 Satellite EPIRB 406MHz / 1.6 GHz 05112 VHF EPIRB 05113 SART/AIS-SART 05114 Reserve source of energy 05115 Radio log (diary) 05116 Operation/maintenance 05117 Other (radio communication) 05118 Operation of GMDSS equipment 06101 Cargo securing manual 06102 Grain 06103 Other cargo - timber -deck/construction 06104 Lashing material 06105 Other (cargo) 06106 Cargo operation		04114	Emergency source of power - Emergency generator
05101 Distress messages: obligations and procedures 05102 Functional requirements 05103 Main installation 05104 MF radio installation 05105 MF/HF radio installation 05106 INMARSAT ship earth station 05107 Maintenance / duplication of equipment 05108 Performance standards for radio equipment 05109 VHF radio installation 05110 Facilities for reception of marine safety information 05111 Satellite EPIRB 406MHz / 1.6 GHz 05112 VHF EPIRB 05113 SART/AIS-SART 05114 Reserve source of energy 05115 Radio log (diary) 05116 Operation/maintenance 05117 Other (radio communication) 05118 Operation of GMDSS equipment 06101 Cargo securing manual 06102 Grain 06103 Other cargo - timber -deck/construction 06104 Lashing material 06105 Other (cargo) 06106 Cargo transfer - Tankers 06107 Cargo operation			
05101 Distress messages: obligations and procedures 05102 Functional requirements 05103 Main installation 05104 MF radio installation 05105 MF/HF radio installation 05106 INMARSAT ship earth station 05107 Maintenance / duplication of equipment 05108 Performance standards for radio equipment 05109 VHF radio installation 05110 Facilities for reception of marine safety information 05111 Satellite EPIRB 406MHz / 1.6 GHz 05112 VHF EPIRB 05113 SART/AIS-SART 05114 Reserve source of energy 05115 Radio log (diary) 05116 Operation/maintenance 05117 Other (radio communication) 05118 Operation of GMDSS equipment 06101 Cargo securing manual 06102 Grain 06103 Other cargo - timber -deck/construction 06104 Lashing material 06105 Other (cargo) 06106 Cargo transfer - Tankers 06107 Cargo operation	05 -	Radio c	ommunication
05102 Functional requirements 05103 Main installation 05104 MF radio installation 05105 MF/HF radio installation 05106 INMARSAT ship earth station 05107 Maintenance / duplication of equipment 05108 Performance standards for radio equipment 05109 VHF radio installation 05110 Facilities for reception of marine safety information 05111 Satellite EPIRB 406MHz / 1.6 GHz 05112 VHF EPIRB 05113 SART/AIS-SART 05114 Reserve source of energy 05115 Radio log (diary) 05116 Operation/maintenance 05117 Other (radio communication) 05118 Operation of GMDSS equipment 06101 Cargo securing manual 06102 Grain 06103 Other cargo - timber -deck/construction 06104 Lashing material 06105 Other (cargo) 06106 Cargo operations	00		
05103 Main installation 05104 MF radio installation 05105 MF/HF radio installation 05106 INMARSAT ship earth station 05107 Maintenance / duplication of equipment 05108 Performance standards for radio equipment 05109 VHF radio installation 05110 Facilities for reception of marine safety information 05111 Satellite EPIRB 406MHz / 1.6 GHz 05112 VHF EPIRB 05113 SART/AIS-SART 05114 Reserve source of energy 05115 Radio log (diary) 05116 Operation/maintenance 05117 Other (radio communication) 05118 Operation of GMDSS equipment 06101 Cargo securing manual 06102 Grain 06103 Other cargo - timber -deck/construction 06104 Lashing material 06105 Other (cargo) 06106 Cargo operation			
05104 MF radio installation 05105 MF/HF radio installation 05106 INMARSAT ship earth station 05107 Maintenance / duplication of equipment 05108 Performance standards for radio equipment 05109 VHF radio installation 05110 Facilities for reception of marine safety information 05111 Satellite EPIRB 406MHz / 1.6 GHz 05112 VHF EPIRB 05113 SART/AIS-SART 05114 Reserve source of energy 05115 Radio log (diary) 05116 Operation/maintenance 05117 Other (radio communication) 05118 Operation of GMDSS equipment 06101 Cargo securing manual 06102 Grain 06103 Other cargo - timber -deck/construction 06104 Lashing material 06105 Other (cargo) 06106 Cargo operation			·
05105 MF/HF radio installation 05106 INMARSAT ship earth station 05107 Maintenance / duplication of equipment 05108 Performance standards for radio equipment 05109 VHF radio installation 05110 Facilities for reception of marine safety information 05111 Satellite EPIRB 406MHz / 1.6 GHz 05112 VHF EPIRB 05113 SART/AIS-SART 05114 Reserve source of energy 05115 Radio log (diary) 05116 Operation/maintenance 05117 Other (radio communication) 05118 Operation of GMDSS equipment 06101 Cargo securing manual 06102 Grain 06103 Other cargo - timber -deck/construction 06104 Lashing material 06105 Other (cargo) 06106 Cargo operations			
05106 INMARSAT ship earth station 05107 Maintenance / duplication of equipment 05108 Performance standards for radio equipment 05109 VHF radio installation 05110 Facilities for reception of marine safety information 05111 Satellite EPIRB 406MHz / 1.6 GHz 05112 VHF EPIRB 05113 SART/AIS-SART 05114 Reserve source of energy 05115 Radio log (diary) 05116 Operation/maintenance 05117 Other (radio communication) 05118 Operation of GMDSS equipment 06101 Cargo securing manual 06102 Grain 06103 Other cargo - timber -deck/construction 06104 Lashing material 06105 Other (cargo) 06106 Cargo operations			
05107 Maintenance / duplication of equipment 05108 Performance standards for radio equipment 05109 VHF radio installation 05110 Facilities for reception of marine safety information 05111 Satellite EPIRB 406MHz / 1.6 GHz 05112 VHF EPIRB 05113 SART/AIS-SART 05114 Reserve source of energy 05115 Radio log (diary) 05116 Operation/maintenance 05117 Other (radio communication) 05118 Operation of GMDSS equipment 06101 Cargo securing manual 06102 Grain 06103 Other cargo - timber -deck/construction 06104 Lashing material 06105 Other (cargo) 06106 Cargo operation			
05108 Performance standards for radio equipment 05109 VHF radio installation 05110 Facilities for reception of marine safety information 05111 Satellite EPIRB 406MHz / 1.6 GHz 05112 VHF EPIRB 05113 SART/AIS-SART 05114 Reserve source of energy 05115 Radio log (diary) 05116 Operation/maintenance 05117 Other (radio communication) 05118 Operation of GMDSS equipment 06101 Cargo securing manual 06102 Grain 06103 Other cargo - timber -deck/construction 06104 Lashing material 06105 Other (cargo) 06106 Cargo operation			· · · · · · · · · · · · · · · · · · ·
05109 VHF radio installation 05110 Facilities for reception of marine safety information 05111 Satellite EPIRB 406MHz / 1.6 GHz 05112 VHF EPIRB 05113 SART/AIS-SART 05114 Reserve source of energy 05115 Radio log (diary) 05116 Operation/maintenance 05117 Other (radio communication) 05118 Operation of GMDSS equipment 06101 Cargo securing manual 06102 Grain 06103 Other cargo - timber -deck/construction 06104 Lashing material 06105 Other (cargo) 06106 Cargo operation			
05110 Facilities for reception of marine safety information 05111 Satellite EPIRB 406MHz / 1.6 GHz 05112 VHF EPIRB 05113 SART/AIS-SART 05114 Reserve source of energy 05115 Radio log (diary) 05116 Operation/maintenance 05117 Other (radio communication) 05118 Operation of GMDSS equipment 06101 Cargo operations including equipment 06102 Grain 06103 Other cargo - timber -deck/construction 06104 Lashing material 06105 Other (cargo) 06106 Cargo operation			···
05111 Satellite EPIRB 406MHz / 1.6 GHz 05112 VHF EPIRB 05113 SART/AIS-SART 05114 Reserve source of energy 05115 Radio log (diary) 05116 Operation/maintenance 05117 Other (radio communication) 05118 Operation of GMDSS equipment 06101 Cargo operations including equipment 06102 Grain 06103 Other cargo - timber -deck/construction 06104 Lashing material 06105 Other (cargo) 06106 Cargo operation			
05112 VHF EPIRB 05113 SART/AIS-SART 05114 Reserve source of energy 05115 Radio log (diary) 05116 Operation/maintenance 05117 Other (radio communication) 05118 Operation of GMDSS equipment 06101 Cargo securing manual 06102 Grain 06103 Other cargo - timber -deck/construction 06104 Lashing material 06105 Other (cargo) 06106 Cargo operation			· · · · · · · · · · · · · · · · · · ·
05113 SART/AIS-SART 05114 Reserve source of energy 05115 Radio log (diary) 05116 Operation/maintenance 05117 Other (radio communication) 05118 Operation of GMDSS equipment 06101 Cargo operations including equipment 06102 Grain 06103 Other cargo - timber -deck/construction 06104 Lashing material 06105 Other (cargo) 06106 Cargo operation			
05114 Reserve source of energy 05115 Radio log (diary) 05116 Operation/maintenance 05117 Other (radio communication) 05118 Operation of GMDSS equipment 06101 Cargo operations including equipment 06102 Grain 06103 Other cargo - timber -deck/construction 06104 Lashing material 06105 Other (cargo) 06106 Cargo operation			
05115 Radio log (diary) 05116 Operation/maintenance 05117 Other (radio communication) 05118 Operation of GMDSS equipment 06101 Cargo operations including equipment 06102 Grain 06103 Other cargo - timber -deck/construction 06104 Lashing material 06105 Other (cargo) 06106 Cargo transfer - Tankers 06107 Cargo operation			
05116 Operation/maintenance 05117 Other (radio communication) 05118 Operation of GMDSS equipment 06 - Cargo operations including equipment 06101 Cargo securing manual 06102 Grain 06103 Other cargo - timber -deck/construction 06104 Lashing material 06105 Other (cargo) 06106 Cargo transfer - Tankers 06107 Cargo operation			<u> </u>
05117 Other (radio communication) 05118 Operation of GMDSS equipment 06 - Cargo operations including equipment 06101 Cargo securing manual 06102 Grain 06103 Other cargo - timber -deck/construction 06104 Lashing material 06105 Other (cargo) 06106 Cargo transfer - Tankers 06107 Cargo operation			
05118 Operation of GMDSS equipment 06 - Cargo operations including equipment 06101 Cargo securing manual 06102 Grain 06103 Other cargo - timber -deck/construction 06104 Lashing material 06105 Other (cargo) 06106 Cargo transfer - Tankers 06107 Cargo operation			<u> </u>
06 - Cargo operations including equipment 06101 Cargo securing manual 06102 Grain 06103 Other cargo - timber -deck/construction 06104 Lashing material 06105 Other (cargo) 06106 Cargo transfer - Tankers 06107 Cargo operation			
06101 Cargo securing manual 06102 Grain 06103 Other cargo - timber -deck/construction 06104 Lashing material 06105 Other (cargo) 06106 Cargo transfer - Tankers 06107 Cargo operation		00110	
06101 Cargo securing manual 06102 Grain 06103 Other cargo - timber -deck/construction 06104 Lashing material 06105 Other (cargo) 06106 Cargo transfer - Tankers 06107 Cargo operation	06	Cargo	nerations including equipment
06102 Grain 06103 Other cargo - timber -deck/construction 06104 Lashing material 06105 Other (cargo) 06106 Cargo transfer - Tankers 06107 Cargo operation	- 00	_	
06103 Other cargo - timber -deck/construction 06104 Lashing material 06105 Other (cargo) 06106 Cargo transfer - Tankers 06107 Cargo operation			-
06104 Lashing material 06105 Other (cargo) 06106 Cargo transfer - Tankers 06107 Cargo operation			
06105 Other (cargo) 06106 Cargo transfer - Tankers 06107 Cargo operation			
06106 Cargo transfer - Tankers 06107 Cargo operation			
06107 Cargo operation			
Oaigo delisity deciaration			
		00100	Cargo density declaration



07 - Fire safety 07101 Fire prevention structural integrity 07102 Inert gas system 07103 Division – decks, bulkheads and penetrations 07104 Main vertical zone 07105 Fire doors/openings in fire-resisting divisions	
 07101 Fire prevention structural integrity 07102 Inert gas system 07103 Division – decks, bulkheads and penetrations 07104 Main vertical zone 07105 Fire doors/openings in fire-resisting divisions 	
 07103 Division – decks, bulkheads and penetrations 07104 Main vertical zone 07105 Fire doors/openings in fire-resisting divisions 	
07104 Main vertical zone07105 Fire doors/openings in fire-resisting divisions	
07105 Fire doors/openings in fire-resisting divisions	
2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2	
07106 Fire detection	
07107 Fire patrol	
07108 Ready availability of fire fighting equipment	
07109 Fixed fire extinguishing installation	
07110 Fire fighting equipment and appliances	
07111 Personal equipment	
07112 Emergency escape breathing Device and disposition	
07113 Fire pumps and its pipes	
07114 Means of control (opening, pumps) Machinery spaces	
07115 Fire-dampers	
07116 Ventilation	
07117 Jacketed high pressure lines	
07118 International shore-connection	
07119 Other (fire safety)	
07120 Means of escape	
07121 Crew alarm	
07122 Fire control plan	
07123 Operation of Fire protection systems	
07124 Maintenance of Fire protection systems	
07125 Evaluation of crew performance (fire drills)	
08 - Alarms 08101 General alarm	
08102 Emergency signal 08103 Fire alarm	
08104 Steering-gear alarm	
08105 Engineer's alarm	
08106 Inert gas alarm	
08107 Machinery controls alarm	
08108 UMS-alarms	
08109 Boiler-alarm	
08110 Closing watertight doors alarm	
08111 Other (alarms)	
09 - Working and Living Conditions	
091 - Working and Living Conditions - Living conditions	
09101 Minimum age	
09102 Dirty, parasites	
09103 Ventilation (Accommodation)	
09104 Heating	



Code	Defective item
09105	Noise
09106	Sanitary facilities
09107	Drainage
09108	Lighting (Accommodation)
09109	Pipes, wires (insulation)
09110	Electrical devices
09111	Sickbay
09112	Medical equipment
09113	Access/structure
09114	Sleeping room
09115	No direct openings into sleeping rooms cargo/mach.
09116	Furnishings
09117	Berth dimensions, etc.
09118	Clear head
09119	Messroom (location)
09120	Oil skin locker
09121	Laundry Decord of ingression (Accompandation)
09122 09123	Record of inspection (Accommodation) Other (crew and accommodation)
09123	Galley, handlingroom (maintenance)
09127	Cleanliness
09128	Provisions quantity
09129	Provisions quality
09130	Water, pipes, tanks
09131	Cold room
09132	Cold room temperature
09133	Cold room cleanliness
09134	Food personal hygiene
09135	Food temperature
09136	Food segregation
09137	Record of inspection
09138	Other (food)
	and Living Conditions - Working Conditions
09201	Ventilation (Working spaces)
09202	Heating
09203	Lighting (Working spaces) Safe means of access
09204 09205	Safe means of access Safe means of access shore – ship
09206	Safe means of access deck - hold/tank, etc.
09207	Obstruction/slipping, etc.
09208	Protection machinery
09209	Electrical
09210	Machinery
09211	Steam pipes and pressure pipes
09212	Danger areas
	J



Code	Defective item
09213	
	Gas instruments
09214	Emergency cleaning devices
09215 09216	Other (working space ILO)
	Personal equipment
09217	Warning notices
09218	Protection machines/parts
09219	Pipes, wires (insulation)
09220	Structural features (ship)
09221	Entry dangerous spaces Other (assident proportion)
09222 09223	Other (accident prevention)
09223	Gangway, accommodation-ladder
09225	Stowage of cargo
09226	Loading and unloading equipment
09227	Holds and tanks safety
09228	Ropes and wires Anchoring devices
09229	Winches and capstans
09230	Adequate lighting mooring arrangements
09231	Other (mooring)
09232	Cleanliness of engine room
09233	Guards / fencing around dangerous machinery parts
09234	Night working for seafarer under the age of 18
09235	Fitness for duty – work and rest hours
09236	Legal documentation on work and rest hours
00200	Logar documentation on work and root riodio
10 - Safety o	f Navigation
10101	Pilot ladders and hoist/pilot transfer arrangements
10102	Type approval equipment
10103	Radar
10104	Gyro compass
10105	Magnetic compass
10106	Compass correction log
10107	Automatic radar plotting aid (ARPA)
10109	Lights, shapes, sound-signals
10110	Signalling lamp
10111	Charts
10112	Electronic charts (ECDIS)
10113	Automatic Identification System (AIS)
10114	Voyage Data Recorder (VDR) / Simplified Voyage Data Recorder (S-VDR)
10115	GNSS receiver/terrestrial radio navigation system
10116	Nautical publications
10117	Echo sounder
10118	Speed and distance indicator
10119	Rudder angle indicator
10120	Revolution counter
10121	Variable pitch indicator
	<u> </u>



Code	Defective item
10122	Rate-of-turn indicator
10122	
	International code of signals- SOLAS
10124	Life-saving signals
10125	Use of the automatic pilot
10126	Records of drills and test steering gear
10127	Voyage or passage plan
10128	Navigation bridge visibility
10129	Navigation records
10130	Other (navigation)
10132	Communication - SOLAS Chapter V
10133	Bridge operation
10134	HSC operation
10135	Monitoring of voyage or passage plan
10136	Establishment of working language on board
10137	Long-Range Identification and Tracking system (LRIT)
	ing appliances
11101	Lifeboats
11102	Lifeboat inventory
11103	Stowage and provision of lifeboats
11104	Rescue boats
11105	Rescue boat inventory
11106	Fast rescue boats
11107	Stowage of rescue boats
11108	Inflatable liferafts
11109	Rigid liferafts
11110	Stowage of liferafts
11111	Marine evacuation system
11112	Launching arrangements for survival craft
11113	Launching arrangements for rescue boats
11114	Helicopter landing and pick-up area
11115	Means of rescue
11116	Distress flares
11117	Lifebuoys incl. provision and disposition
11118	Lifejackets incl. provision and disposition
11119	Immersion suits
11120	Anti-exposure suits
11121	Thermal Protective Aids
11122	Radio life-saving appliances
11123	Emergency equipment for 2-way comm.
11124	Embarkation arrangement survival craft
11125	Embarkation arrangements rescue boats
11126	Means of recovery of life saving appliances
11127	Buoyant apparatus
11128	Line-throwing appliance
11129	Operational readiness of lifesaving appliances



Code	Defective item
11130	Evaluation, testing and approval
11131	On board training and instructions
11132	Maintenance and inspections
11133	Other (life saving)
11134	Operation of Life Saving Appliances
11135	Maintenance of Life Saving Appliances
12 - Dangero	ous Goods
12101	Stowage/segregation/packaging of dangerous goods
12102	Dangerous liquid chemicals in bulk
12103	Liquefied gases in bulk
12104	Dangerous goods code
12105	Temperature control
12106	Instrumentation
12107	Fire protection cargo deck area
12108	Personal protection
12109	Special requirements
12110	Tank entry
12111	Other (tankers)
12112	Dangerous goods or harmful substances in pack. form
13 - Propuls 13101	ion and auxiliary machinery Propulsion main engine
13102	Auxiliary engine
13103	Gauges, thermometers etc.
13104	Bilge pumping arrangements
13105	UMS-ship
13106	Insulation wetted through (oil)
13107	Other (machinery)
13108	Operation of machinery
	n Prevention n Prevention - MARPOL Annex I
14101	Control of discharge of oil
14102	Retention of oil on board
14103	Segregation of oil and water ballast
14104	Oil filtering equipment
14105	Pumping, piping and discharge arrangements
14106	Pump room bottom protection
14107	Oil discharge monitoring and control system
14108	15 PPM alarm arrangements
14109	Oil / water interface detector
14110	Standard discharge connection
14111	SBT, CBT, COW
14112	COW operations and equipment manual
14113	Double hull construction



Code	Defective item
14114	Hydrostatically balanced loading
14115	Condition Assessment Scheme
14116	Pollution report - MARPOL Annex I
14117	Ship type designation
14118	Other (MARPOL Annex I)
14119	Oil and oily mixtures from machinery spaces
14120	Loading, unloading & cleaning procedures cargo spaces of tankers
14121	Suspected of discharge violation
142 - Pollution	n Prevention - MARPOL Annex II
14201	Efficient stripping
14202	Residue discharge systems
14203	Tank washing equipment
14204	Prohibited discharge of NLS slops
14205	Cargo heating systems - cat. Y substances
14206	Ventilation procedures / equipment
14207	Pollution report - MARPOL Annex II
14208	Ship type designation
14209	Other (MARPOL Annex II)
143 - Pollution	n Prevention - MARPOL Annex III
14301	Packaging
14302	Marking and labelling
14303	Documentation (MARPOL Annex III)
14304	Stowage
14305	Other (MARPOL - Annex III)
144 - Pollution	n Prevention - MARPOL Annex IV
14402	Sewage treatment plan
14403	Sewage comminuting and disinfecting system
14404	Sewage discharge connection
14405	Other (MARPOL Annex IV)
145 - Pollution	n Prevention - MARPOL Annex V
14501	Garbage
14502	Placards
14503	Garbage management plan
14504	Other (MARPOL Annex V)
146 - Pollution	n Prevention - MARPOL Annex VI
14601	Technical Files and if applicable, monitoring manual
14602	Record book engine parameters
14603	Approved doc exhaust gas cleaning system
14604	Bunker delivery notes
14605	Type approval certificate of incinerator
14606	Diesel engine air pollution control



Code	Defective item
14607	Quality of fuel oil
14608	Incinerator incl. operations and operating manual
14609	Volatile Organic compounds in tankers
14610	Operational proc. for engines or equipment
14611	Ozone depleting substances
14612	Other (MARPOL ANNEX VI)
14613	Approved method
14614	Sulphur oxides
147 - Pollution	n Prevention - Anti Fouling
14701	AFS supporting documentation
14702	Logbook entries referring AFS
14703	Paint condition
14704	Other (AFS)
15 - ISM	
15150	ISM
16 - ISPS	
16101	Security related defects
17 - Other	
17101	Other safety in general
17102	Other (SOLAS operational)
17103	Other (MARPOL operational)

ⁱ Paris MoU assumes no liability or responsibility for any errors or omissions.